

## PATTERN TILING FOR YIELDS!

## **Narrow Spacings**

Modern farm drainage means pattern tiling with narrow lateral spacings. We're talking 40' laterals — or less — depending on soil permeability and other factors. Narrow laterals promote uniform stand and maximum yield.

## Shallow Depths

Lateral

Comprehensive water table management is not possible without shallow lateral depths. Keeping laterals in the 30" – 36" keeps an ideal balance of oxygen and moisture in the root zone.

Lateral

Both stand and ear size illustrate the need for narrow lateral spacings.





Now is the time to invest in your future - and do it right - while you still can.

**Exclusive Financing Opportunities** Timewell's unique financing opportunities aren't available anywhere else. This program, available through participating drainage contractors, makes pattern tiling for \$120/acre a reality.

**Resources to Do It Right** Find out about tools for comprehensive water management planning and Edge-of-Field practices.

800-720-8453 timewellpipe.com